KETTLER®

CARE & MAINTENANCE INSTRUCTIONS

RESIN

Clean at the start and end of each season using warm, soapy water. Remove sap, bird droppings and sunscreen promptly. Avoid abrasives and pressure washers. Breathable covers may help protect furniture.

WROUGHT IRON / WROUGHT IRON MESH TABLE TOPS

Brush off debris; wipe with a soft cloth and mild dish soap in warm water. Rinse and allow to dry. Never use abrasive cleaners or power washers.

ALUMINUM / ALUMINUM TABLE TOPS

Wipe with a soft cloth and warm water mixed with mild dish soap. Rinse thoroughly and allow the surface to dry.

ALL-WEATHER WICKER

Remove debris between strands with a vacuum or soft brush. Wipe with mild soapy water and rinse with a medium-pressure hose. Avoid bleach, abrasives and high-pressure washers.

TEAK / TEAK TABLE TOPS

Wash along the grain with a soft brush or cloth, mild soap and water a few times yearly. Avoid power washing, abrasives, paint, varnish and oils. Do not cover tightly; allow airflow. Natural silvering and fine checks are normal. Avoid treatments during the first 3–4 months.

TEXTILENE SLING

Remove debris with a soft-bristle brush. Wipe using mild dish soap and warm water; rinse and let dry.

SUNBRELLA CUSHION FABRICS

Brush away dirt and clean spills quickly. Use ¼ cup mild soap per gallon of lukewarm water, gently brush, rinse fully and air dry. Clean upholstery seam-to-seam to avoid water rings. For mildew, follow KETTLER's fabric-specific bleach cleaning directions.

POLY RECYCLED RESIN TABLE TOPS

Wash with mild detergent and warm water; remove spills promptly. Avoid abrasive cleaners, hot cookware, barbecue sparks, sharp impacts and glassware that concentrates sunlight. Slight heat-related warping can be temporary.

HIGH-PRESSURE LAMINATE (HPL) TABLE TOPS

Remove debris with a damp sponge; clean with mild dish soap and warm water. Rinse and air dry. Avoid abrasive, strongly acidic or bleach-containing cleaners.

CERAMIC TABLE TOPS

Remove dirt with a damp sponge or gentle garden hose. Wash with mild dish soap and warm water using a soft cloth; rinse and dry.

GENERAL CARE

Regular cleaning helps protect furniture from outdoor conditions. Allow surfaces to dry before storage and follow product-specific guidance when it differs from this summary.

For full care details: kettlerusa.com/pages/materials-and-maintenance

PANGAEA PATIO